

HANSEN TIMBER

HARDWOOD AND ENGINEERED FLOORING INSTALLATION GUIDE



Hansen Timber Hardwood and Engineered Flooring must be installed by a qualified Floor Installer or Tradesperson who has experience laying a floor.

Preparation of the site is vital along with the acclimatisation of the Flooring in the environment prior to laying the floor. All wet work must be complete and dry prior to laying the Timber floor.

Reach out to Hansen Timber if you need a recommendation for an installer.



32 Eyres Road, Clevedon, Auckland 2585

Website: www.hansentimber.co.nz/

www.hansenflooring.co.nz

Ph: 09 242 3644



After Care / Maintenance:

- Maintain room temperature between 15° - 29° C; relative humidity between 40% and 70%
- Avoid bringing dirt, water and sand indoors by providing a suitable floor mat at all outside doors. Sweep and/or dust mop the floor daily to remove surface dirt. Remember to clean walk-off mats regularly.
- Strong alkaline detergents or cleaning agents containing solvents should not be used.
- We recommend the Bona Floorcare Wood Floor Spray or another gentle Wood Floor cleaner for regular cleaning and removing grease and smudges from your floor.
- Do not use harsh abrasive cleaners, bleach, ammonia or vinegar-based cleaners, wax or acrylic polishes, or oil soaps. These may dull or damage the floor.
- Protect your floor against direct sunlight or any intense source of artificial lighting. Over time, intense natural and artificial light may discolor the timber.
- Do not roll, or drag heavy objects across your floor. Do not wear shoes having heel taps, spikes, cleats, rocks, gravel or sharp objects protruding from the sole.
- Protect furniture and chair legs with proper felt or rubber caps.

